

KevinsOffroad.com

Installation Guide for Hard-KOR Steering Box Brace

- 1) Remove the factory front skid plate under the radiator, if your model has one
- 2) Locate the anti-sway bar, which is a bar about 1" thick that mounts on both the left and right frame rails
- 3) Remove the clamshell clamp bolts holding the anti-sway bar to the driver-side frame rail
- 4) Replace the clamshell clamp with the new clamshell clamps you picked up from the auto parts store (or ordered from us) threading both bolts in only 3 turns.
- 5) Do the same on the passenger side frame rail.
- 6) The steering box brace mounts between both frame rails utilizing the FORWARD-MOST clamshell bolts on each anti-sway bar clamp on the ZJ Grand Cherokee, and between both frame rails utilizing the REARWARD-MOST clamshell bolts on each anti-sway bar clamp on the XJ Cherokee, circling the "neck" of the steering box, bracing it in two planes.
- 7) Leave everything finger-tight until you're sure that everything fits properly, then tighten down the bolts on the anti-sway bar clamps.
- 8) Tighten the bolts around the steering box "neck".
- 9) Enjoy your MUCH tighter steering response, as well as the reduced propensity for Death Wobble! Thank you for your loyalty and your order!! -Kevin