



DESCRIPTION

Ensure power is off.

- A. Loosen side grub screws with allen key provided.
- B. Ensure your main wire has the correct coppering.
- C. Push your wire through the back of the canopy.
- D. Mark where to drill your holes.
- E. Use the fixtures provided to mount your canopy.
- F. Connect your terminals.
- G. Push the fitting onto the wall and tighten side grub screws.
- H. Place your G9 Bulb and twist your bulb on to the fitting.

