



**DESCRIPTION**

1. Fix the ceiling bracket to the ceiling using all the provided mounting holes.
2. Once the ceiling bracket is securely fixed to the ceiling, allow the plate to suspend freely from the 4x 20cm steel wires attached.
3. From below, feed the electrical cable of the pendant lights through the grooves.
4. Use the provided cord gripping attachments to allow the cables to be securely held in place, preventing the pendants from dropping.
5. Once all your fittings have been positioned into the correct slot, neaten cables by securing them gently to the loops on the inside of the plate wall.
6. Once all cables neaten and electrical connection is completed, lift plate and align protruding screws with L shaped grooves on the side of the plate walls.
7. Lock in place by tightening screws.
8. The threaded rod will be protruding out the centre of the plate, fix this in place using the provided dome nut.
9. The fittings may have moved slightly and this can now be adjusted as needed.

