

Cat A Arm Install

- Remove hood and front nose guard
- Measure ski center to center
- Next remove the 5 pushdarts on L & R sides that hold the rubber to bulkhead



- Remove upper arm
- Lower A Arm Leave shock connected and hit next to ball joint with hammer while putting pressure on ski to get balljoint out of spindle



- When installing a arms the lowers screw ball joints out 3 full turns to be at stock width, the upper arms do the same.
- Once all assembled you can check camber and ski width