



Polaris PRO R & PRO XP Grill Install

Difficulty: 3/10

Estimated Time: 10 Minutes

Step 1: Remove Oem center grill by pushing 2 plastic tabs down on top of grill to release it.

For PRO XP skip Step 2

Step 2: Mount the side grills using the 4 allen bolts w/lock nuts and backer plate
The backer plate goes behind stock vent.
Tighten bolts to secure aluminum cover over stock vent.





Polaris PRO R & PRO XP Grill Install

Step 3: Mount center grill using 2 supplied phillips screws and 2 spacers.
The spacers go on the back of grill to space it out.

