



DAX-136-1T



SHOWER PANELS **SERIES**



www.daxib.com



SHOWER PANEL DAX-136-1T

MODEL	DAX-136-1T
ADA	No
UPC APPROVED	Yes
ANSI APPROVED	No
ASME APPROVED	No
BODYSPRAYS INCLUDED	Yes
NUMBER OF BODYSPRAYS	2
HAND SHOWER FLOW RATE (GPM)	2.5
SHOWER HEAD FLOW RATE (GPM)	2.5
ROUGH-IN VALVE FLOW RATE (GPM)	3.5
HANDLE MATERIAL	Brass
HANDLE STYLE	on panel
HAND SHOWER INCLUDED	Yes
HAND SHOWER HOSE INCLUDED	Yes
HAND SHOWER HOSE LENGTH	1.5M
INSTALLATION TYPE	Wall Mounted
MATERIAL	Stainless Steel 304
PRESSURE BALANCE	Yes
SCALD GUARD	Yes
SHOWER ARM REACH	No
SHOWER HEAD	Yes
SHOWER HEAD HEIGHT	2.2M
SHOWER HEAD SHAPE	Rectangular
SHOWER HEAD WIDTH	13-3/4"
SLIDE BAR INCLUDED	No
SPRAY PATTERN	Rain, Body spray, Hand shower
THERMOSTATIC	No
VALVE INCLUDED	TW Henyou
VALVE TYPE	Pressure Balance
WATER EFFICIENT	Yes
WATERSENSE CERTIFIED	No
WALL ELBOW DIMENSION	G1/2" female
FINISH	Brushed Stainless Steel

For parts or sale requirements please contact our customer service department:

 CS@daxib.com


 1 888 685 8236





Chart1
Flush the water supply lines throughly to drain debris and impurities. Shut off the water before installation.

Chart2
Assemble the shower arm with the panel and PVC water pipe behind. Screw the top shower to the shower arm.

Chart5
Choose proper location for your shower panel and mark the position of the holes .

Chart6
Drill the holes in the wall. Insert the wall plugs into the holes. Fix the two wall mounting brackets with self-tapping screws.

Chart3
Complete assembly of shower holder as instructed .

Chart4
Connect shower hose to the shower holder and hand shower. Don't forget to put rubber washers inside both connection nuts.

Chart7
Connect inlet hoses with water supply hoses accordingly. Red for HOT and blue for COLD.

Chart8
Hang the shower panel on the mounting brackets securely on the wall.

For parts or sale requirements please contact our customer service department:

CS@daxib.com

1 888 685 8236

