

# Control Arm Skids Installation



Hook the bent taab into the outside hole on the control arm.  
Slide the plate into position on the arm and then reattach the  
swaybar link.



Hook Tab here





Put the bolt through the offset spacer and washer as shown



Align the bolt to the threaded nut. You can look through the hole in the control arm to make it easier.





Tighten down the bolt, making sure the offset spacer keeps the bolt head flat on the washer. The casting bumps of the control arm will determine the rotation of the spacer. It does not need to be directly over the hole.





Job complete!

