

Defender 2

MUD FLAP MOD





When you have successfully completed the following instructions, your mud flaps should look like this.



Mark the inside edge of the mud flap at 5/8"



Cut into the upper section



Trim from the end to your mark. Do not cut flush
leave about 1/16th



Line up your support bracket with the first hole.



Notch the sport bracket so it will not interfere with the slider.



Place nut and bolt on the 2 ends of the sport bracket.
You will need to drill a new hole in the flap
for the innermost bolt.



Test fit to make sure there is not interference with the slider.



Pull the inner fender liner out



With the mud flap bolted to the side trim it should look like this when it is put into place.



This hole needs to be aligned under the bracket with the Rover logo.



With the mud flap in place mark
your location with a scribe.



Drill the hole.



Mount the mud flap to the side of the truck and bolt the center location into place.



Reinstall the liner.



Congratulations!