

QuikStart CARPET CLEANING SYSTEM

RESIDENTIAL

NYLON – LIGHT TO MEDIUM SOIL

PRESPRAY:

- PUMP UP- 300ML **HOTSHOT UHT** PER 10LTR OF HOT WATER
- HYDROFORCE (8:1) – 1.3LTRS OF **HOTSHOT UHT** THEN FILL 4.75LTR CONTAINER WITH WATER

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)

WOOL – LIGHT TO MEDIUM SOIL

PRESPRAY:

- PUMP UP- 300ML **HOTSHOT UHT** PER 10LTR OF HOT WATER
- HYDROFORCE (8:1) – 1.3LTRS OF **HOTSHOT UHT** THEN FILL 4.75LTR CONTAINER WITH WATER

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)

POLYPROP – LIGHT TO MEDIUM SOIL

PRESPRAY:

- PUMP UP- 300ML **POWERSHOT UHT** PER 10LTR OF HOT WATER
- HYDROFORCE (8:1) – 1.3LTRS OF **POWERSHOT UHT** THEN FILL 4.75LTR CONTAINER WITH WATER

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)

COMMERCIAL

NYLON - HEAVY SOIL & GREASE

PRESPRAY:

- PUMP UP- 300ML **HOTSHOT UHT** PLUS 100ML **CITRABOOST** PER 10LTR OF HOT WATER,
- HYDROFORCE (8:1) – 1 LTR OF **HOTSHOT UHT** PLUS 240ML **CITRABOOST** THEN FILL 4.75LTR CONTAINER WITH WATER

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)

WOOL - HEAVY SOIL & GREASE

PRESPRAY:

- PUMP UP- 300ML **HOTSHOT UHT** PLUS 100ML **CITRABOOST** PER 10LTR OF HOT WATER,
- HYDROFORCE (8:1) – 1 LTR OF **HOTSHOT UHT** PLUS 240ML **CITRABOOST** THEN FILL 4.75LTR CONTAINER WITH WATER

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)

POLYPROP - HEAVY SOIL & GREASE

PRESPRAY:

- PUMP UP- 50CC **OXYBOOST** PLUS 300ML **POWERSHOT UHT** PER 10LTR OF HOT WATER
(DISOLVE OXYBOOST IN A LITTLE WARM WATER BEFORE ADDING POWERSHOT)
- HYDROFORCE (8:1) – 120CC **OXYBOOST** PLUS 1 LTR OF **POWERSHOT UHT** THEN FILL 4.75LTR CONTAINER WITH WATER
(DISOLVE OXYBOOST IN A LITTLE WARM WATER BEFORE ADDING POWERSHOT)

EXTRACT:

PORTABLE:

- 150ML **e-RINSE EFR** PER 10LTRS OF HOT WATER

TRUCKMOUNT:

- 1LTR **e-RINSE EFR** PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)



TRUCKMOUNTS . PORTABLES . DRYING & RESTORATION EQUIPMENT . CHEMICALS & ACCESSORIES

For more information call 1800 68 68 69

10/535 Zillmere Road
Zillmere QLD 4034,
Phone: 07 3326 7500
Fax: 07 3326 7599

Unit 2/8 Tollis Place
Seven Hills NSW 4563,
Phone: 02 8868 0000
Fax: 02 8868 0099

Unit 1/5 Gatwick Road
Bayswater North VIC 3153
Phone: 03 9720 8700
Fax: 03 9720 8799

www.ccwonline.com.au


**Carpet Cleaners®
Warehouse**

YOUR PARTNERS IN CLEANING & RESTORATION SUCCESS!

HYDRAMASTER – BRIDGEPOINT – HYDRO-FORCE – DRI-EAZ – RAZORBACK & MORE

QuikStart UPHOLSTERY CLEANING SYSTEM

NATURAL	SYNTHETIC
USE FOR: COTTON, WOOL, VELVET, WATER CLEANABLE SILK, LINEN, RAYON & ANY FABRIC SUBJECT TO BROWNING, WICKING OR WATER MARKING	USE FOR: NYLON, POLYPROPYLENE & POLYESTER
NATURAL – LIGHT TO MEDIUM SOIL	SYNTHETIC – LIGHT TO MEDIUM SOIL
PRESPRAY: <ul style="list-style-type: none"> 60ML HOTSHOT UHT PER 1LTR OF HOT WATER EXTRACT: PORTABLE: <ul style="list-style-type: none"> 150ML e-RINSE EFR PER 10LTRS OF HOT WATER TRUCKMOUNT: <ul style="list-style-type: none"> 1LTR e-RINSE EFR PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH) 	PRESPRAY: <ul style="list-style-type: none"> 60ML POWERSHOT UHT PER 1LTR OF HOT WATER EXTRACT: PORTABLE: <ul style="list-style-type: none"> 150ML e-RINSE EFR PER 10LTRS OF HOT WATER TRUCKMOUNT: <ul style="list-style-type: none"> 1LTR e-RINSE EFR PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)
NATURAL – HEAVY STAINS & BODY OILS	SYNTHETIC – HEAVY STAINS & BODY OILS
PRESPRAY: <ul style="list-style-type: none"> 60ML HOTSHOT UHT PLUS 20ML CITRABOOST PER 1LTR OF HOT WATER EXTRACT: PORTABLE: <ul style="list-style-type: none"> 150ML e-RINSE EFR PER 10LTRS OF HOT WATER TRUCKMOUNT: <ul style="list-style-type: none"> 1LTR e-RINSE EFR PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH) 	PRESPRAY: <ul style="list-style-type: none"> 60ML POWERSHOT UHT PER 1LTR OF HOT WATER EXTRACT: PORTABLE: <ul style="list-style-type: none"> 150ML e-RINSE EFR PER 10LTRS OF HOT WATER TRUCKMOUNT: <ul style="list-style-type: none"> 1LTR e-RINSE EFR PER 20LTR OF WATER TO MAKE UP STOCK SOLUTION (SET METERING AT 3GPH)
HELPFUL HINTS <ul style="list-style-type: none"> • PRE INSPECT AND TEST ALL FABRICS BEFORE CLEANING • PRE-VACUUM • ALLOW 5 TO 10 MINUTES DWELL TIME BEFORE EXTRACTING PRESPRAYS • AGITATE PRESPRAYS WITH HORSE HAIR BRUSH OR BONNET MIT • DO NOT ALLOW PRESPRAY TO DRY BEFORE EXTRACTION • APPLY HYDRAMASTER FIBREGARD CARPET & FABRIC PROTECTOR FOR COMPLETE CUSTOMER SATISFACTION • DRY UPHOLSTERY QUICKLY WITH THE USE OF AIRMOVERS 	

QuikStart SPOTTING GUIDE

- BLOT UP SPILLS WITH WHITE TOWEL
- REMOVE SOLID BUILD UP WITH TAIL OF SPOTTING BRUSH
- PRE TEST FOR COLOUR FASTNESS

