

OPERATING INSTRUCTIONS

INSERTING ACCESSORIES

- Remove rubber plug from stainless steel block.
- 2. Make sure handle is in the spring-loaded position before installing the insertion pin. If necessary, turn clockwise.
- 3. Position hand directly under insertion pin and insert accessory into the opening. Do not slam the insertion pin if it does not insert. Move back and forth slightly, applying force to the center.
- 4. When the handle releases, the accessory is latched.
- 5. Press the lock until it clicks.







OPERATING INSTRUCTIONS



REMOVING ACCESSORIES

- 1. Unlock the receiver by inserting the key and turning clockwise 90°. Do not attempt to turn the handle until the lock has popped out.
- 2. Support the accessory firmly. It will release as you turn the handle clockwise. The lock and handle are now in position to receive the next accessory or the plug.



DO NOT EXCEED VEHICLE WEIGHT RATINGS