

VB95

Multi Court Volleyball Storage System



Customer Service
(800) 247-7668

PARTS LIST					
Item	Qty	Description	Item	Qty	Description
A	2	Cart Side	G	2	5/16" X 1" Carriage Bolt
B	5	Horizontal Bars (packaged separately)	H	4	5/16" Hex Nut
C	10	Bolt Spacer	I	4	5/16" Lock Washer
D	4	Caster	J	2	5/16" X 1 1/2" Hex Bolt
E	1	Brace	K	10	1/2" Cap Screw
F	2	Brace Bracket	L	1	3/8" Hex Bit
M	1	Bungee Cord Stock	N	4	Bungee Cord Hook

- ◆ Inspect all contents prior to installation. Report any missing parts to dealer immediately.
 - ◆ Read all instructions before proceeding.
1. Assemble *Cart Sides (A)* to *Horizontal Bars (B)* using the *3/8" Hex Bit (L)* (not shown), *1/2" Cap Screws (K)* and *Bolt Spacers (C)*. See illustration on page 2.
 2. Install *Brace Brackets (F)* to *Brace (E)* with *5/16" X 1 1/2" Hex Bolts (J)*, *5/16" Lock Washers (I)* and *5/16" Hex Nuts (H)*. Leave hardware finger tight at this time. See illustration on page 2.
 3. Attach *Brace* assembly to *Cart Sides (A)* with *5/16" X 1" Carriage Bolts (G)*, *5/16" Lock Washers (I)* and *5/16" Hex Nuts (H)*. Tighten all hardware. See illustration on page 2.
 4. Install *Castors (D)* into the bottom of *Cart Sides (A)*. See illustration on page 2.
 5. Load all of your post padding on the top rack of the storage system. Knot one end of *Bungee Cord Stock (M)*, slide one *Bungee Cord Hook (N)* tight to knot. Attach *Bungee Cord Hook (N)* to one end of *Cart Side (A)*. Drape *Bungee* assembly over post padding to the other side of *Cart Side (A)* just enough to take the slack out and cut to length. Slide *Bungee Cord Hook (N)* onto *Bungee Cord Stock (M)* and knot to complete assembly. **NOTICE!** Do not over stretch *Bungee Cord Stock (M)*, damage to post padding could occur. Repeat process on the other end of storage system. See illustration on page 2

