



# EXPRESS WAX PROCEDURE

**TIME STANDARD: 15 - 20 MINUTES**

| Application                       | Product   | Tools   | Procedure / Pro Tips  |
|-----------------------------------|---|---|---|
| Vehicle Prep                      |   |   | <p>Wash vehicle to remove loose contaminants</p> <p>Place keys on top of the driver's front tire</p>  |
| Above Surface Defect Removal Clay |   |   | <ol style="list-style-type: none"> <li>1. Check vehicle for bonded surface contamination.</li> <li>2. Clay vehicle with Clay Mitt - Fine utilizing Clay Lube Spray. Dilute 1:1</li> </ol> <p><b>PRO TIPS:</b></p> <p>Work in 2'X2' grid areas frequently spraying Clay Mitt with Clay Lube. Wipe off Clay Lube Spray with microfiber after completion of each panel. (2'x2' areas)</p> <p>Apply to paint, glass and chrome surfaces.</p> <p>Store Clay Mitt in Microfiber cloth and keep out of direct sunlight and heat.</p>                           |
| Express Wax                       |  |  | <ol style="list-style-type: none"> <li>1. Beginning with the middle of the driver's side hood work your way bumper to bumper addressing all paint surfaces.</li> <li>2. Apply 1oz to 6 oz (per vehicle) of Express Wax Gold directly to the Microfiber Applicator.</li> <li>3. Spread wax in a 2x2 area, working one panel at a time. Product does not need to be removed immediately.</li> <li>4. Once all painted surfaces have been covered, begin to wipe off with 2 microfiber towels. One for initial wipe off and 2nd for final wipe.</li> </ol> |