



56 PATCHES

**FOR ALL RUBBER REPAIRS
JUEGO DE PARCHES**

Proper Use:

- Lightly buff area around puncture with metal scuffer, removing loose particles. Make sure the entire area within ½" (13mm) of puncture has roughened appearance.
- Squeeze rubber cement onto roughened surface and spread evenly. Work into material and wait until tacky.
- Remove protective backing. Be careful not to touch exposed surface of patch.
- Apply repair material directly over puncture and press firmly. Using a stitching tool (not included), ensure the edges of the patch are firmly attached.
- Remove protective coating (if applicable).

Uso Apropriado:

- Limpie el área que esta ponchado con el removedor de metal y remueva las partículas sueltas, asegurando que toda el área dentro de ½" (13mm) de la perforación adquiera una apariencia áspera.
- Presione el cemento de caucho sobre la superficie áspera y esparza de manera uniforme. Frote el material hasta que quede pegajoso.
- Retire la parte protectora trasera del parche. Cuidado de no tocar la superficie adhesiva del parche.
- Aplique el material de reparación directamente sobre la punción y presione con firmeza. Utilice una herramienta de parchado (no incluida), asegúrese de que los bordes del parche estén firmemente unidos.
- Retire la parte protectora del parche (en caso de que aplique)