

POLYVINE SATIN + DEAD FLAT VARNISH APPLICATION GUIDE

Why Choose Satin Varnish + Dead Flat Varnish mix?

The durability of a Satin with the matt finish of the Dead Flat? This combination gives you the best of both worlds, less glossy than a satin but also providing more durability than the Dead Flat.

Choose the Satin + Dead Flat Mix varnish for: our magnetic wallpapers.

How Many Litres will I need?

Satin + Dead Flat Mix: Per roll of our wallpaper, we recommend 2 coats of Satin (approximately 500ml) plus 1 coat Dead Flat (500ml)

SURFACE PREPARATION FOR ALL VARNISHES

Ensure the surface to be coated is clean and free from grease, wax or polish.

Use the lint cloth provided to wipe clean the wallpapered surface.

Please wipe clean the surface again between coats as dust may have settled during the drying time.

TOOLS REQUIRED

Lint-free cloth (included with your varnish purchased from us)

A good synthetic brush for the corners and edges of the wall

[Mini gloss rollers simulated mohair 4" x 24mm](#)



DRYING/RECOATING TIME

Drying time: 1 to 2 Hours at 20°C / 70°F

Optimal temperature for applying the varnish: approximately 8°C - 23°C (it is not recommended to apply the varnish outside of this temperature range)

Please note: low temperature/high humidity increases drying time.

Cure Time: Up to 5 days at 20°C / 70°F

Recoat Time: Up to 2 Hours at 20°C / 70°F

LIFETIME: Re-apply the varnish after 3-5 years.

HEALTH, SAFETY AND THE ENVIRONMENT

Non-hazardous. Ensure good ventilation. Keep out of reach of children. If in contact with eyes, wash immediately with warm water. Remove excess from tools and mixing vessels before washing in warm soapy water. Do not empty containers into drains or watercourses. No fire hazard before or during use, or in the cured state.

CLEAN UP

Any equipment used can be cleaned using soap and water before the clear coat dries. Wipe any excess off surfaces with a damp cloth. Any dried deposits will need a paint stripper to remove them.

STORAGE

Store in unopened containers in a cool dry place away from direct sunlight.

SATIN + DEAD FLAT MIX

APPLICATION

Apply 2 coats of Satin followed by 1 coat of Dead Flat using the rollers recommended in our tools section. Use the synthetic brushes to cover the edges of the wall. Allow 1 to 2 hours drying time between coats. Please note: low temperatures or high humidity increases the drying time.

It can take up to 5 days for the varnish to fully cure/harden. Do not scrub or touch the varnished wall until it's fully hardened.

If cissing occurs, rub the affected area with a damp cloth to break the surface tension and Re-apply.

Please note: Over time and with multiple wipes, the surface of your wallpaper may become shinier as the top (matt) layer of the Dead Flat varnish wears off. To bring back the matt look, please re-apply the Dead Flat varnish as and when needed.

The information supplied herein is accurate to the best of our knowledge. Since conditions and methods are beyond our control, no warranty is expressed or implied. You are advised to access the suitability of the product on a test area before application.