

# POLYVINE SATIN VARNISH APPLICATION GUIDE

## Why choose Satin

Because the satin varnish is more durable than the Dead Flat, use satin on your wallpaper in high-traffic areas, or if you prefer a slightly glossier finish to your wallpaper design.

Not recommended for our Fibrous Hua Trees and Clematis Wallpapers unless applied by an experienced decorator.

## How Many Litres will I need?

Satin: 15-20 square metres/ litre (Per roll of our wallpapers: Recommended 3 coats, approximately 1 L per roll of wallpaper)

## SURFACE PREPARATION FOR ALL VARNISHES

Ensure the surface to be coated is clean and free from grease, wax or polish.

Use the lint cloth provided to wipe clean the wallpapered surface.

Please wipe clean the surface again between coats as dust may have settled during the drying time.

## TOOLS REQUIRED

Lint-free cloth (included with your varnish purchased from us)

A good synthetic brush for the corners and edges of the wall

[Mini gloss rollers simulated mohair 4" x 24mm](#)



## DRYING/RECOATING TIME

Drying time: 1 to 2 Hours at 20°C / 70°F

Optimal temperature for applying the varnish: approximately 8°C - 23°C (it is not recommended to apply the varnish outside of this temperature range)

Please note: low temperature/high humidity increases drying time.

Cure Time: Up to 5 days at 20°C / 70°F

Recoat Time: Up to 2 Hours at 20°C / 70°F

**LIFETIME:** Re-apply the varnish after 3-5 years.

### **HEALTH, SAFETY AND THE ENVIRONMENT**

Non-hazardous. Ensure good ventilation. Keep out of reach of children. If in contact with eyes, wash immediately with warm water. Remove excess from tools and mixing vessels before washing in warm soapy water. Do not empty containers into drains or watercourses. No fire hazard before or during use, or in the cured state.

### **CLEAN UP**

Any equipment used can be cleaned using soap and water before the clear coat dries. Wipe any excess off surfaces with a damp cloth. Any dried deposits will need a paint stripper to remove them.

### **STORAGE**

Store in unopened containers in a cool dry place away from direct sunlight.

## **SATIN**

### **APPLICATION**

Satin: Apply 2-3 coats using the rollers recommended in our tools section. Use the synthetic brushes to cover the edges of the wall. Allow 1 to 2 hours of drying time between coats.

Please note: low temperature or high humidity increases the drying time.

It can take up to 5 days for the varnish to fully cure/harden. Do not scrub or touch the varnished wall until it's fully hardened.

If cissing occurs, rub the affected area with a damp cloth to break the surface tension and re-apply.

The information supplied herein is accurate to the best of our knowledge. Since conditions and methods are beyond our control, no warranty is expressed or implied. You are advised to access the suitability of the product on a test area before application.