Important Tips!

Always use caution during hot weather as the mount may become extremely hot – especially in direct sunlight. Never leave your phone in the mount unattended during hot weather.

Always allow the phone holder to cool down before use. Failure to do so could damage the rubber pads on the universal holder.

Some local governments have specific rules, regulations and laws regarding how phone mounts must be used and positioned as it relates to driver visibility. Please ensure your installation complies with the laws in your area and never obstruct or impair the driver's ability to have an unobstructed view of the road.

It is the sole responsibility of the customer/user (and not Bulletpoint Mounting Solutions) to know and understand the laws in your area and any other area where the mount is used. Bulletpoint Mounting Solutions is not responsible for illegal or improper use of mounting hardware.

Never place any device in the way of any SRS airbag system for any driver or passengers. Check with your local dealership or your vehicle manufacturer to understand how your airbag deploys in the event of an accident.











Bulletpoint Mounting Solutions



Thank you for choosing Bulletpoint Mounting Solutions!

Congratulations on your purchase! Our industry-leading mounts were developed by off-road enthusiasts with more than two decades of automotive industry experience.

Tough. Solid. Secure.

Exclusive Carbon Fiber/Kevlar Hybrid Arms

Our proprietary arms are engineered for added strength and durability

Single Barrel Design

Your dash mount was developed with simplicity, function and durability in mind and this kit includes everything you need for a quick/easy installation.

Off-Road Ready

Your dash mount kit has been tested in some of the harshest off-road environments.

If you have any questions during the installation process, please email us at support@bulletpointmountingsolutions.com









Bulletpoint Mounting Solutions

Why Choose **Bulletpoint Mounting Solutions?**



Superior Engineering and Design – Our engineers designed each of our products to exceed your expectations. Every aspect of your new mount was designed to exacting standards.



Extreme Value – We design every product with quality and affordability in mind. We think you'll agree that our products provide the best value for your money.



Warranty – We're so confident in our products that we offer an industry-leading limited lifetime warranty. If your product fails for any reason under normal use, simply return it to us and we will send you a replacement. No questions asked – period. See site for details



We support the Jeep Community – As avid offroad enthusiasts, we support off-road clubs in the U.S. and around the world.

Veterans and Law Enforcement



Bulletpoint Mounting Solutions supports veterans, active-duty military and law enforcement officers. A portion of our profits are donated to charities supporting our heroes.

Visit BulletpointMountingSolutions.com for more information

Installation

Installation of your mounting base should take 5-15 minutes. If you have any questions during the installation process, please reach out to us via email at support@bulletpointmountingsolutions.com

Step 1 – Remove the rubber cover from the dash tray and set aside.

Step 2 – JK OWNERS – Use a 7mm socket to remove the original equipment (OE) bolt found under dash pad above the center console. **JL OWNERS** – Use a small Phillips-Head head screwdriver to remove the OE fastener screw found on the angled portion under the dash tray.

Step 3 – Set the mounting base in place taking note of where the adhesive tape contacts the tray.

Step 4 – Thoroughly clean the tray where the adhesive tape will make contact.

Step 5 – Remove the adhesive tape backing and carefully press the base into place ensuring alignment of the fastening holes.

Step 6 – Reinstall the OEM fastening screw. **JL OWNERS** – For added stability we include <u>optional</u> screws to further secure the base. Use the additional supplied screws if desired.

Step 7 - Allow the adhesive tape to cure for 24 hours.

Step 8 – **JL OWNERS** – Use a pair of scissors to carefully trim the dash tray liner to the proper length for a finished appearance.

Step 9 – Attach the phone mount arm and phone holder to the base. NOTE – during the first 30 days it is normal to find that you need to periodically tighten the mounting arm.

Step 10 – Take pics of your installed mount and post them to Instagram or Facebook. Use the hashtags #bulletpointmounts and #mountit to be featured on our social media pages!









Bulletproint Mounting Solutions



