

# INSTALLATION INSTRUCTIONS

## NOMAD™ SERIES SWING OUT TIRE CARRIER



**Application:** Add On Accessory for Nomad Series Rear Swing Out

Thank you for choosing Backwoods Adventure Mods for your bumper! We value our customers and the off road lifestyle.

**Safety First!** Thoroughly read all instructions and warnings before beginning the installation. Use your own judgment and, if necessary, have the installation done by a professional.

This bumper is intended for off-road use only. The owner assumes all liability for installation and use. Any sensor will have an altered view when installed in an after-market bumper.

### **Hardware Kit Included:**

BW00-0032

**Accessories are designed to be installed after the bumper install is completed. Please refer to the bumper installation manual.**

1. Determine which side you want to place the tire carrier. We recommend you install the tire carrier on the same side as the swing out latch. Typically, this would be the passenger side of the van.
2. Press the lug studs into the lug stud holes. The holes are marked with an "S" for Sprinter and "T" for Transit. If a press is not available, you can use a hammer and punch. Just center the hole over an opening in a vise or anvil. **Picture 1-2**



3. Using four of the included bolt sets, install the front half of the tire carrier onto the accessory panel. Using the remaining three bolt sets, install the rear half of the tire carrier onto the front half. There are multiple slotted holes to choose from. This allows you to set the correct depth for your wheel and tire combination. **Picture 3-6**

