NOTE: IF YOU ARE UNSURE ABOUT GENERAL FITMENT PLEASE CONTACT US BEFORE YOU START FITTING THIS COMPONENT TO YOUR VEHICLE.

TRUNDLES CANNOT BE HELD RESPONSIBLE FOR ANY FURTHER MODIFICATIONS OR DEVIATIONS FROM THE GIVEN INSTRUCTIONS LAID OUT IN THIS FITTING GUIDE.

RECOVERY POINT (RPCRU70E) FITTING GLIDE

AUTOMOTIVE LT

TOYOTA LANDERUISER 76 SERIES


1. Each side uses 2 x M10x1.25mm x 60L & 1 x M10x1.25 x 40L bolts (inserted from the inside of the chassis rail). High-tensile bolts supplied, with relevant flat & split washer.

2. The longer bolts are for the holes spaced from the chassis, with the shorter bolt for the top front hole. All models have nuts retained in chassis, ready for fitment.

3. The mounts themselves are sided, so please ensure installation to the correct side of the vehicle. In some circumstances, the RPCRU70E has been designed to protrude through the aftermarket Skid Plate where one is installed.

4. In some instances, depending upon the skid plate installed, you might need to trim two 100mm (long) x 40mm (wide) holes on each side to allow for the skid plate to be refitted.

5. Ensure three bolts per tow point are fitted and torqued to recommended settings to ensure tow points meet tested standards.







installation of tow points. Failure to do so will significantly reduce the Working Load Limit (WLL) specified for each individual point (5000kgs), which can result in serious injury or death.

All bolts to be tightened to the appropriate torque value based on nominal size, pitch and grade, or OE manufacturer's specs.

| | 8.8 | 10.9 | 12.9 |
|-----|------------|------------|------------|
| M10 | 41-60 Nm | 59-85 Nm | 65-94 Nm |
| M12 | 71-105 Nm | 102-150 Nm | 114-164 Nm |
| M14 | 112-168 Nm | 161-240 Nm | 182-265 Nm |
| M16 | 175-260 Nm | 250-371 Nm | 282-406 Nm |





TRUNDLES AUTOMOTIVE LTD – 4X4 Specialist 159 Gill St. New Plymouth sales@trundlesautomotive.com – www.trundlesautomotive.co.nz



TESTED TO 5000KGS PER TOW POINT

HARDWARE SUPPLIED WITH RPCRU70E

1x RPCRU70EL Tow Point 1x RPCRU70ER Tow Point 4x M10 x 1.25 x 60L Bolts 2x M10 x 1.25 x 40L Bolts 6x Flat Washers 6x Split washers

Ensure all supplied and specified

components are used during the