

# Hard Shell Lock Installation Instructions



## INCLUDED PARTS:

- 2 locking clasps
- 2 keys
- 2 straps
- 4 washers
- 12 rivets
- 1 rivet gun (pictured below)



## REQUIRED TOOLS:

- Drill (#9 / 5mm bit)
- 13 mm spanner
- Rivet gun (included)



## INSTRUCTIONS

1. Loosen the mounting bracket nuts using a 13mm spanner.
2. Push the Skycamp to the passenger side of the vehicle so that you have easy access to the fastening straps and the rivets located under the aluminum panel.
3. Using a #9 (5mm) drill bit, drill out the rivet holding the buckle. Repeat the process on the other side.



4. Take the locking clasp, place a rivet in the top right hole, and insert it into the hole previously created in the hard shell.



5. Make sure the locking clasp is level, then drill through the hard shell using the holes from the locking clasp.



6. Place a rivet into the hole, and rivet it into place.



7. Repeat the process with the remaining rivet

- Using the key, lock the clasp. Make sure the latch at the bottom is securely screwed in.



- Drill out the rivet holding the strap under the aluminum panel.



- Take a rivet, place it in the hole just created, and rivet it closed.



11. Fix the strap into the latch. Using one hand, pull down on the hard shell, and with the other, pull the latch under the aluminum panel and mark where the two holes need to be drilled.



12. Drill the two holes into the panel. Do NOT drill completely through the panel, only the first layer.



13. Place the rivets through the bottom of the strap, and put the washers on the end touching the aluminum panel.



14. Rivet in both rivets to attach the strap.



15. Repeat the process on the other side.

16. Finished!





**[ikamper.com](http://ikamper.com)**