

Mounting Brackets 1.0

Included: 4 Bracket Sets, 10 Bolts (including 2 spares), 10 nylon threaded nuts (includes 2 spares).

Please follow these instructions for an optimal installation.

- **STEP 1:** Take the top bracket (w/square holes), and insert two bolts according to the width of your cross bars.
- **STEP 2:** Insert top bracket with the two bolts into the mounting rails.
- **STEP 3:** Have one person lift the RTT, while another person slides the piece over the crossbar, so that one bolt is on each side of the cross bar.
- **STEP 4:** Take the bottom bracket (with the round holes), and fit it under your cross bar so that the bolts go through the holes.
- **STEP 5:** Attach one nut on each bolt, and tighten using a 13mm ratchet. **NOTE:** Using a power tool at high speeds can damage the bolt threads, making it extremely difficult to loosen the nuts later on. In which case the bolts will have to be cut off.
- **STEP 6:** Tighten the nuts until the bottom bracket starts to bend lightly. Do **NOT** overtighten the nuts. Overtightening can cause the bottom bracket and bolts to bend as well, making it extremely difficult to remove the nuts later.
- **STEP 7:** Repeat steps 1-6 on remaining 3 brackets.



IMPORTANT: WHEN MOUNTING THE SKYCAMP / SKYCAMP MINI / X-COVER ON YOUR VEHICLE, MAKE SURE THAT EACH BRACKET IS SECURELY FASTENED. FAILURE TO DO SO COULD CAUSE DAMAGE, INJURY OR EVEN DEATH.

If you have any questions, please contact us at support@ikamper.com

