

Mounting Brackets 2.0

Included: 8 Bracket Components, 4 Allen Bolts (8mm), 4 Threaded Brackets, 4 Unthreaded Brackets, 4 Rail End caps, Allen Wrench.

Please follow these instructions for an optimal installation.

- **STEP 1:** Separate all 4 sets to prepare for installation. Leaving the threaded brackets to be entered first.
- **STEP 2:** Insert threaded bracket into the mounting rail with the curved portion facing outwards. (see image below)
- **STEP 3:** Have one person lift the RTT, while another person slides the piece to the inside of the crossbar.
- **STEP 4:** Slide the remaining bracket with the bolt into position to be threaded into the threaded bracket. (please remove bolt while sliding into position to avoid scratching vehicle).
- **STEP 5:** Use the provided 6mm wrench to tighten brackets locking your RTT into position.



IMPORTANT: WHEN MOUNTING THE SKYCAMP / SKYCAMP MINI / X-COVER ON YOUR VEHICLE, MAKE SURE THAT EACH BRACKET IS SECURELY FASTENED. FAILURE TO DO SO COULD CAUSE DAMAGE, INJURY OR EVEN DEATH.

If you have any questions, please contact us at support@ikamper.com