



1) Clear any packaging debris from the post hole.

2) Line up the arrow on the post with the arrow on the base.



3) Insert the post completely (you will not be able to insert it completely unless the arrows are lined up).



4) While holding the post in position, screw in the base screw on the underside of the base to secure the post to the base. Finger-tighten the screw securely but do not over-tighten the base screw.