

Advice for correct fitting of the kit : Do not fully tighten the bolt until it's ensured that the KIT is correctly attached and aligned.

Cara pasang yang benar : Jangan sepenuhnya kencangkan baut sampai dipastikan bahwa KIT terpasang dengan benar dan selaras.

1.



Open the handle pillion of motorbike by disassembly original bolts
(Buka handle pillion sepeda motor dengan melepaskan baut orisinil)

2.



Put part no.3 in to motorbike then Assembly part no.2 (short metal part in front and long metal part in rear)by using part no.5
(Letakan part no.3 di motor kemudian pasang part no.2 (Part pendek didepan dan part panjang dibelakang) menggunakan part no.5)

3.



Install the fitting kits in to motorbike by using part no.4
(Pasang bracket pada motor menggunakan part no.4)