w: www.escapegear.co.za

TYPICAL SINGLE CAB FITTING INSTRUCTIONS





VERY IMPORTANT

a.) PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE COMMENCING WITH ANY FITMENT.

TOOLS AND MATERIALS REQUIRED TO FIT

Clean hands, short fingernails and no open wounds.

CAUTION

Ensure that your workmanship is of the highest professional standard and that you do not soil, scratch or damage the vehicle or accessory you are about to fit.

Ensure that you make provision for a clean area, to place components removed.



: +27(21) 706-0440 e: <u>orders@escapegear.co.z</u>

w: www.escapegear.co.za

INSTALLATION PROCEDURE - Remove all headrests and loosen all webbing straps and buckles on seat covers.

STEP 1

Passenger seat. Pull cover over seat bottom and feed buckles through the gap between the backrest and seat bottom.



Passenger seat. Feed 2 front and 2 side webbing straps underneath the seat and tie to the buckles at the back of the seat.



Passenger seat. Positions and smooth out seat covers and tighten straps securely.



Passenger seat. Make sure there is nothing in the pocket at the back of the seats and pull backrest cover over backrest as you would a jersey and feed Velcro trough gap in the middle of the backrest and seat bottom.



Passenger seat. Align backrest cover with seat and join Velcro together at the back of the seat. Driver seat – as per passenger seat.



Consol cover. Carefully slide elasticized webbing to fit the underside of console.

STEP 7

Consol cover. Now fold the sides of the consol cover over and adjust for a neat fit.

STEP 8

Headrest covers. When done fitting the seat covers replace all headrests and cover with headrests covers. Pull down for snug fit.