



HOW TO APPLY

Follow the steps below to add realistic and detailed ARCKITEXTURE finishes to your completed model

1. PRINT YOUR ARCKITEXTURE FINISH

Browse the ARCKITEXTURE library and download your chosen finish.

Open the downloaded Jpeg image file on your computer and insert ARCKITEXTURE adhesive vinyl sheets into your inkjet printer, making sure they are inserted correctly for printing.

You're now ready to print off your textures.

2. MEASURE THE APPLICATION AREA

Use a ruler to measure the surface area where you intend to apply the finish.

If you don't have a ruler then this can be done quickly by holding the adhesive sheet over the intended area of the model and marking the area lightly with a pencil.

Then cut the measured area with a scalpel or scissors (we advise that this is only done by adults).

3. APPLY THE ARCKITEXTURE FINISH

Make sure that the application area is clean and dry before applying the ARCKITEXTURE Media adhesive sheet. Carefully remove the backing paper and position the exposed edge of adhesive against one edge of the application area. Slowly remove the remaining backing paper, carefully and smoothly applying the ARCKITEXTURE finish.

Alternatively, remove the backing paper completely and apply. If the ARCKITEXTURE adhesive needs to be realigned, carefully peel off and reapply.

Important! Inkjet printer required! Images from the ARCKITEXTURE library may vary in quality depending on your printer. MBM Building Systems assumes no responsibility and shall not be liable for any damages caused to printers by the use of ARCKITEXTURE adhesive sheets provided by us or purchased elsewhere.