

## Arctic Walk-in Optional Style Door Sweep Installation

1. Hardware included is: (1) one wide metal channel, (1) one slim metal channel and (1) one rubber piece.



2. Open the door at 90° and take the door out of the hinges by gently lifting the door plug. Place the door on a flat working surface. Please make sure you have padding to avoid denting or scratching your door plug.
3. Tuck the rubber piece inside the wider channel and adjust until equal in height. Check that it extends about the same on both sides. You should end up with a “taco” that has the wide metal channel for a shell and the rubber piece inside. Now, place the slim channel inside and push down to close the assembly.



4. Install door sweep at the bottom of the “belly” of the door and anchor it with sheet metal screws (#8-1” or longer self-drilling metal screw).



5. Installation of the assembly is finished.

6. Re-install the door plug following in reverse the instructions from step 2.  
Trim excess with a utility knife. Measure twice, trim once!!

