

Use your vacuum system to put your abrasive sleeves on and take them off the 73200 arbor.

Follow these three easy steps

1. Slide your sleeve onto the 73200 as far as it will comfortably go. Assure the seam on your sleeve has been given directional consideration.
2. Place one end of the 73200 against your vacuum pipe and cover the open end with your hand.
3. Apply vacuum and center the sleeve on the 73200 arbor, release vacuum and proceed with fabricating.

Due to the release agent used when manufacturing the 73200 arbors you may experience the arbor sliding down your carver shaft. With repeated applications the release agent will wear off and this condition will subside.

