



MANUFACTURED BY:
CROWD CONTROL
WAREHOUSE

Kit Includes:

- 2 lbs Grout Mixture
- 10 oz Bonding Agent
- 4 Spray Cans of Sealer

Additional Items Needed:

- Rubber Gloves
- #80 Grit Sand Paper
- #240 Sand Paper
- Pail
- Sanding Block
- Sponge
- Mixing Tool
- Squeegee
- Scrubbing Pad

Note: Wear rubber gloves during entire refinishing process. Refinishing results are best when all excess grout is removed and surface is sanded smooth. Check for and clean up spills after each step. Newly refinished tables will retain an attractive appearance for several years if they are resealed at least once a year.



One kit will refinish four Wausau Made table sets. If more than four tables are to be finished, additional kits will need to be purchased.





1. Scrub and Rinse

Rinse surface with water while using scrubbing pad to remove dirt and grime. Using the sanding block and #80 sand paper, sand surface. Repeat rinse.



2. Grout

Mix grout and bonding agent together to create a creamy consistency in a pail. Allow to set for 5 minutes. Apply to the surface using a circular motion, with a sponge to fill all voids. Can be used on smooth edges, not on acid wash surfaces.

Note: Acid wash edges to be taped off before grouting the surface to avoid getting grout in pores of edge.



3. Remove Excess Grout

Immediately remove all excess grout with a squeegee. Apply water as needed to keep grout moist with a spray bottle. Thoroughly inspect the surface to be certain it is clean. Allow to cure for approximately 24 hours.



4. Wet-Sand

Once the surface has cured, wet-sand grouted surface using sanding block, #240 sandpaper and water.



5. Clean

Thoroughly rinse with water and allow to dry. Surface must be dust free. If tape was needed for edges remove tape before cleaning the surface.



6. Seal

Apply sealer to the refinished area and edges using an even back and forth motion. After sealer is dry, remove any rough spots by buffing with clean scrubbing pad.