

Pry Shield Installation Instructions

1.



The Pry Shield should be installed on the outside door frame centered to cover the deadbolt and door knob. If the door knob and deadbolt are spaced too far apart, center the Pry Shield with the deadbolt.

2.



Start by marking the holes you will be pre-drilling with the Pry Shield against the frame.

3.



Pre-drill the three marked holes you made in step two with an 11/64" drill bit.

4.



The kit comes with three Tamper Proof screws (with painted heads).

Use either a Flat Head Drill bit or flat head screwdriver to install the screws into the pre-drilled holes.

5.



Recommended Equipment

- 1 - Variable speed drill, with screwdriver adapter and bits
- 1 - Flat tip drill bit or flat head screwdriver
- 1 - 11/64" drill bit

Painting Instructions

(Note: It will be easiest if the Pry Shield components are painted before they are installed. They can then be touched up as necessary after installation.)

1. Using plain steel wool or very fine emery cloth gently rough the surface of the piece and area to be painted. Understand that you only want to rough the surface and break the gloss. Do not totally remove the existing powder coating.
2. Clean the surface with a tack cloth or a cloth with a cleaner on it that will not leave a residue. Rubbing alcohol will work well for this application. You can also use mineral spirits or other chemicals but make sure that whatever you use does not cause an adverse reaction with the power coating.
3. When components are clean and free of debris you are ready to paint your pieces.