



Joining Stand Assembly Instructions

Large 2m x 1m



Firstly assemble the 2 medium stands as per their directions - but don't fully tighten bolts that are holding the cross brace tubes.

1. Align stands with cross members running long ways
2. Undo and remove the 2 bolts of middle 2 cross members where the stands join
3. Place spacing bars (that are packaged separately) across gap and re-insert and tighten all bolts – also at far end of cross brace tubes as these may have been left loose.

IMPORTANT *****

ENSURE STANDS ARE ON FLAT LEVEL GROUND

If placing the stands on lawn or soft surfaces - Ensure the legs are placed on footings made from pavers or bricks that are level to prevent the legs sinking into the earth.

Once filled the large Vegepod can weigh up to 400kgs. So please ensure stand is secure, stable and flat before filling with soil.