BLUEPRINT LIGHTING NYC

- 1. Hold the mounting plate to the wall and mark two dots in the center of each horizontal channel.
- 2. Drill the two pilot holes using a 1/4" drill bit and place the provided dry wall anchors inside.
- 3. Position the mounting plate on the wall so that the channels line up with the drywall anchors.
- 4. Drill the 2 provided screws into the drywall anchors so that the mounting plate sits flush on the wall.
- 5. Place the raised backplate onto the mounting plate.
- 6. Rotate the raised backplate until all three side holes line up with the corresponding holes on the mounting plate.

