

FLUORIDE TEST SAMPLING INSTRUCTIONS



PLEASE READ ALL INSTRUCTIONS COMPLETELY BEFORE COLLECTING YOUR WATER SAMPLE



This test kit represents one sampling location. If you require testing on multiple locations you will need to purchase multiple test kits.

- 1. Run the cold water for approximately 3-5 minutes, then adjust the flow to a thin stream to avoid splashing or overfilling.
- 2. Fill the bottle to the neck, cap securely.
- 3. Complete the enclosed lab form, making sure to indicate the collection date and time you sampled, type of water (treated/untreated) and sample identification which identifies where you collected your sample (i.e., kitchen sink, well head, etc.). Retain a copy of the lab form for your records and return the completed form to the shipping container.
- 4. It is not necessary to ship by an overnight delivery service. Ground, Saver, or 2nd day delivery is sufficient. Cost of shipping samples to the laboratory is at your expense. NTL offers discounted UPS shipping, if interested call for a quote or to obtain your label

Testing Location: National Testing Laboratories, Ltd.

556 South Mansfield Street Ypsilanti, MI 48197

5. PLEASE NOTE: Testing typically takes approximately 5-7 business days from receipt of the samples. Results will be emailed upon completion.

NOTE: The lab reserves the right to reject water samples that appear to be excessively contaminated as they may cause potential damage to laboratory equipment.

If you have any questions regarding this Fluoride Test or any other services we provide, please contact a Technical Service Representative at National Testing Laboratories at 1-800-458-3330 for assistance.

Thank you for choosing National Testing Laboratories, Ltd., for your water testing services!