

DECKING INSTALLATION



STEP BY STEP GUIDE

Step 1

Complete installation of your decking structure. Ensure it is sound and ready for the decking boards.

Step 2

Attach the first board. Make sure that it is aligned and square with the edge of the deck. Install Clipz on each joist. Make sure they are secure, but not completely screwed in/too tight, as it is vital that the next decking board is able to slip underneath Clipz.

Step 3

Push your next board up to the one you have just installed. If you push the boards tightly together, a perfect 6mm gap will be made by Clipz.

Step 4

While the boards are pushed together, screw the clip down tightly. This secures both boards.

Step 5

Continue to attach the boards and Clipz until you have completed the decking area right up to the end of your space/building.

Step 6

Pre-drill and screw down the L-Trim all the way around your decking *PRO-TIP – Secure the L-Trim using a bonding agent before you screw it down.*

