

Instruction to apply thermal transfer printing to a garment

- Preheat the iron to the recommended temperature for the heat transfer vinyl.
(Normal-130C-140C or 266F-284F)
- Place the T-shirt on a flat surface and position the heat transfer vinyl on the desired location.
- Cover the heat transfer vinyl with a thin cloth or Teflon sheet to protect it from direct heat.
- Apply firm pressure with the iron for 10-15 seconds, moving it around to ensure even heat distribution.
- Let the vinyl cool for a few seconds before peeling off the transfer sheet.
- If necessary, repeat the process with the cloth or Teflon sheet until the vinyl is fully adhered to the T-shirt.
- Allow the T-shirt to cool completely before wearing or washing.

Please use the electric iron with caution and pay attention to safety.

