

B R I T I S H *C U S T O M S*

18426 South Broadway
Gardena, CA 90248
Toll Free: +1 (877) 999-BRIT support@british-customs.com
www.britishcustoms.com

Brake Master Cylinder Cover

PART NUMBERS: *BC703-003B* *BC703-006B*
 BC703-004B *BC703-007B*
 BC703-005B



Tools Required: *Phillips Screwdriver*
 3mm Allen Wrench
 Clean Microfiber Cloth
 Rubbing Alcohol

WARNING: Always properly support vehicle with a stand and/or lift when servicing or performing any work.

Unstable vehicles may present dangerous conditions and may cause property damage and/or personal injury.

NOTE: Read through all instructions before beginning installation.

Removal

1. With clean microfiber cloth and rubbing alcohol, wipe down the master cylinder and surrounding area.



2. Loosen the two factory Phillips screws.



3. Carefully lift off the factory master cylinder cover. Take care to not pull out the inner plastic piece and rubber diaphragm.



Installation

1. With clean microfiber cloth, wipe down the edges of the master cylinder, taking care to not lift the inner plastic piece or rubber diaphragm.



2. Install the British Customs Master Cylinder cover and insert the supplied 3mm allen screws.



3. In an alternating pattern, tighten each screw until snug. You want even pressure on each side of the cover while tightening to prevent leaks.



Once snug, firmly tighten each screw to **2 Nm (17 in-lbs)**
***Note Inch-Pounds**



Wipe down the master cylinder and surround area with a clean microfiber cloth and rubbing alcohol to remove any fingerprints, oils, or brake fluid.

If any problem is found, please carefully follow through the installation steps again. If problem still persists, please call **British Customs Customer Support at (877) 999-2748.**