

Instructions for assembling the Cat Shark







CONTENTS

Your shark includes 6 cardboard pieces;

1x main body internal lining,
1x main body external shell
2x pectoral side fins,
1x dorsal top fin
1x caudal tail fin

and a bag of 12x press screws

INTERNAL LINING

Starting with the internal lining (this has no printing on the outside), pre-press all fold lines.

NOTE: There is a smooth side and a side with faint lines. The side with the faint lines should end up on the inside.

Using two sets of the press screws, join the two flaps on the left and right of the shark. You will need to squeeze firmly on the screws for them to close. They do not need to be fully closed but firm enough to give the shark strength.

NOTE: The flat side of the screw should be facing out.



Spin the lining around and now join the two flaps on the left and on the right of the shark with two more sets of screws.

Altogether these 4 screws have helped form the top of the internal lining.

EXTERNAL SHELL

Now take the external shell and again pre-press all the fold lines. This makes it easier when putting it together.

NOTE: The side with the printing will be on the outside.



As shown insert folded tabs (1) into slot (2), ensure you insert the tabs so that the tabs appear on the inside of the shark.

From the inside of the shark it should look like the following image.





EXTERNAL SHELL - Continued

The flap can now be unfolded to secure join.





The back of the shell will now need to be secured together with two sets of screws.

- 1. fold in both 1 flaps
- 2. bring 2 up over the top of 1, but under 3.
- Then bring down 3 so that the holes on 2 and 3 align. Making sure you remember to tuck in the two side pieces of 3 (these are shown in the next picture).

Now that's clear as mud, bring the tongue back in (3) and secure with the screws.

This picture shows you the side pieces of fold 3, and what it should look like from the inside of the shark. The three gills on either side of the shark can now be folded in.

Our shark is really taking form now ③ YAY..





INTERNAL LINING

Yes, back to the internal lining... One last thing before it gets inserted into the shell.

There are three folds that will need to be pushed in. One on the tope that you can see quite clearly here. The other two are on either side of the lining.





INSERT LINING INTO THE SHELL





SECURING SHELL TO LINING

Align holes on either side of the shark's shell and secure with two sets of screws. Both sides of the shell should look the same as this picture.

NOTE: The holes that need to be aligned can be seen at the top left of the picture above.

SECURING SHELL TO LINING -Continued

The round flaps indicated are attached to the bottom rows of teeth. They need to be brought up and in. Ensure that all three holes align and secure with two sets of screws.







FINISHING TOUCHES

Now to attach;

1x dorsal top fin

1x caudal tail fin

2x pectoral side fins

Once in, they should all look like this on the inside....



CONGRATULATIONS YOU NOW HAVE A BONA FIED CAT SHARK FOR YOUR FURRY FAMILY MEMBER...

Do remember that some cats are cautious of new surroundings, we recommend encouraging your family member with perhaps some treats placed inside, or some teasing with a toy. However, you know your cat the best so enjoy and don't forget to take some pictures.

from our family to yours...

