



EVO 3 HOLE DERBY COVER INSTALL

PART NO. 06-98 / 921017

For technical support contact Joker Machine
2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403
PHONE: 909-596-9690, FAX: 909-596-9693
sales@jokermachine.com, www.jokermachine.com

NEEDED FOR INSTALLATION

- 5/32 Hex Allen Driver/T-handle
- Blue Loctite
- Gasket

INSTALLATION

NOTE: Use blue Loctite on hardware
NOTE: New gasket recommended on every install

1. Try to level motorcycle. There's oil behind the derby cover.
2. Place oil catch pan under motorcycle. If bike is level oil shouldn't spill out.
3. Remove stock cover and gasket.
4. Install derby cover and gasket with (3) button head screws.

