



## HEADLIGHT BRACKET INSTRUCTIONS

### PART NO. 10-531

For technical support contact Joker Machine  
2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403  
PHONE: 909-596-9690, FAX: 909-596-9693  
sales@jokermachine.com, www.jokermachine.com

### TOOLS NEEDED

- 3/4" Socket
- T40 Torx Driver
- 1/4" Allen Driver/T-handle
- 9/16" 12-Point Wrench/Socket
- Blue Loctite

### INSTALLATION

NOTE: Use blue Loctite on all hardware

1. Remove the plug that's covering the stock headlamp shell nut.
2. Support headlamp and remove nut.
3. Keep lock washer and HD swivel washer. Will be re-used when installing Joker Machine headlight bracket.
4. Remove torx screws holding the stock bracket to the upper tree.
5. Install Joker Machine headlight bracket with the 5/16-18 socket cap screws provided.
6. Install headlight with stock lock washer, HD swivel washer and provided 12-point flange nut. Adjust headlight to desired position while tightening down 12-point flange nut.

#### (2) 5/16-18 SOCKET CAP SCREWS

