



INDIAN FOOTPEG INSTALLATION

For technical support contact Joker Machine

2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403

PHONE: 909-596-9690, FAX: 909-596-9693

sales@jokermachine.com, www.jokermachine.com

NOTE: USE MEDIUM THREAD LOCKER ON ALL HARDWARE

DISCLAIMER: Joker Machine denies any responsibility for any issues that may be caused from failure to use liquid thread locker on all hardware listed below

TOOLS NEEDED

- 5/16 12 Point Wrench
- 1/8 Allen Key/Driver
- 5/32 Allen Key/Driver
- 6mm Allen Key/Driver
- 13mm Socket
- Medium Thread Locker (Loctite)
- Retaining Ring Pliers

Installation is easier in some cases if you remove the footpeg from mount first.

1. Install footpeg to stock footpeg mount using the hardware Joker Machine provided.
2. Loosen 1/4" set screws found on the bottom of some footpegs, and 5/16" 12 point screw if footpeg is still together after step 1. This will allow you to adjust the peg.
3. Adjust footpeg to desired position and firmly tighten down 5/16" 12 point screw or 1/4" set screws.
4. Adjust pitch adjustment screw found behind footpeg mount as needed.

