



INDIAN SCOUT SIDE RAILS

PART NO. 30-700

For technical support contact Joker Machine
2245 Kiowa Blvd N. Ste. 100, Lake Havasu City, AZ 86403
PHONE: 909-596-9690, FAX: 909-596-9693
sales@jokermachine.com, www.jokermachine.com

NEEDED FOR INSTALLATION

- 6mm T-handle
- 5mm T-handle
- 13mm Wrench / Socket
- Blue Loctite

INSTALLATION

NOTE: Use blue Loctite on hardware

1. Install side rail without locknut.
2. Relocate turn signals if you are going to use wire clamps provided to route the wires.
3. Install locknut. (if using wire clamps make sure they are already installed at this point)
4. Install trim washer if not using the extra hole on fender for turn signals. (Trim washers not required on every install)

