

Emblem Installation Instructions

Must be installed on surfaces at least 60 degrees F or 16 degrees C.

- Step 1- Clean the area of the vehicle where the emblem will be placed. (Make sure all old adhesive is removed)
- Step 2- Use isopropyl alcohol pad or on a clean rag to completely remove any remaining dirt, wax, or grease from the area. Allow plenty of time to completely dry.
- Step 3- Using painters tape and a level make a straight line across the top or bottom of where the emblem will be placed.
- Step 4- Remove the plastic from the tape exposing the adhesive.
- Step 5- Carefully stick the emblem to the vehicle and hold in place for several minutes allowing the pressure sensitive tape enough time for the adhesive to properly bond to the vehicle.

As a seller we are not liable for any loss or damage arising from this product, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted.