

# STA10 OUTDOOR SHOWER

## INSTALLATION GUIDE

1. Have the plumber bring the hot and cold water to the location. If only cold then no problems shower will still work.
2. If installing against the wall, then the services should come up 900 from the ground and discard back plate on shower
3. If installing freestanding, then the services should come below the point of mounting.
4. You will need to put a concrete pad to support the shower base if putting on grass.
5. Fit the hand shower
6. Use brackets to fit on the wall or use included bolts to mount to the concrete pad.
7. Attach braided hoses to the hot and cold services and the installation is complete.

H/C valve, connect the garden hose



Connect with H/C water  
in the bottom

With warm water connector

# SECURING TO A DECK

