

Installation Guide for Drapes

GETTING STARTED

Drapery or curtain rods and rings are not included with your Wovn order. When purchasing a curtain rod, the width should equal the total width of the drapes ordered. The rings will need to have eyelets, but not clips. We recommend purchasing 12 rings for every 50" of drape width.

INSTALL YOUR DRAPE

1. Slide the curtain rings onto the curtain rod, and insert the pre-applied drapery pins through the eyelets of the rings.
2. Hold the curtain rod up to the height you plan to install the rod (with rings and drapes still attached). Adjust the height of the curtain rod based on where you would like the drapes to fall in relation to the floor. Keep in mind that as an organic fiber, linen can grow slightly when absorbing humidity which may make the drapes hang longer over time.
3. Once the height of the curtain rod has been determined, follow the installation directions from the rod manufacturer.
4. After your rod and drapes are installed, most wrinkles and folds will relax on their own. You may also use a steamer to reduce wrinkles.
5. If you need to make a small adjustment to the height of the drapes after the rod is hung, you can lower or raise the drapery pins +/- 1" to make the drapes slightly longer or shorter.

