

Pressure Switch Installation Instructions

Tools Recommended:

- Allen keys, Phillips head screwdriver, Thread tape.

Directions:

- Make sure there is a non-return valve between the pump and the pressure switch.
- Make sure you have the correct fittings for the task before you begin.
- All threads must be thread taped.
- If there is not a tee in the line already, please install one as close to the pump controller as possible.
- Make sure to wire the fork connectors into the terminals marked by the red square in the picture below. Polarity is NOT important.
- With the pump running, test and adjust your pressure switch as necessary by adjusting the allen screw, located between the terminals on the pressure switch body.

