

Bulldog Interconnect Template



TEMPLATE

② Note: Select correct backset
2-3/8" (60mm) or 2-3/4" (70mm)

④ Mark center point of door
thickness for 1" (25mm) hole

⑥ Bore 1" (25mm) hole in
center of door edge.
2" (51mm) 1-3/4" (45mm) 1-9/16" (40mm) 1-3/8"

Along dotted line to fold
and fit door edge. ①

② Note: Select correct backset
2-3/8" (60mm) or 2-3/4" (70mm)

④ Mark center point of door
thickness for 1" (25mm) hole

⑥ Bore 1" (25mm) hole in
center of door edge.
2" (51mm) 1-3/4" (45mm) 1-9/16" (40mm) 1-3/8"

Start approximately
38" (95mm) from floor.

