

Vienna Valance 9209

Also called an Austrian Valance. It attaches to a board with "legs" (in order to stabilize the sides). Instructions are included. The swags can be pleated or gathered with shirr tape. **Swag widths are 20" to 26"** and the **swag depth is 18".** Alteration instructions are included.

There are three decorative alternatives for covering the swag seams. The **Curved Tail** (which protrudes above the top of the board), a traditional **Horn** (which has a straight bottom), and a **Pointed Tab**. These accents are made and attached to the valance seperately.

Fabric Suggestions: Damask, brocade, velvet, chintz, satin, linen, taffeta, morie, most any drapery fabric. Light weight as well as some heavy weight fabrics are good, just make sure they will hold pleats or gathers. The tail and horn pieces should be self lined or contrast lined. The valance should have a compatible drapery lining.

YARDAGE

To determine your swag size, simply divide your board face measurements (do not count "ends") into equal units. Stay within 20" to 26".

With so many different fabric widths and repeats available today, we find it works best if we give you the actual pattern sizes so you can determine how they will fit on your fabric.

Upright Cut SWAG

20" wide	the pattern is	24" wide x 40" deep
26" wide	the pattern is	30" wide x 40" deep
Return	the pattern is	8" wide x 38" deep
Curved Tail	the pattern is	12" wide x 20" deep
Horn	the pattern is	11" wide x 19" deep
	the pattern is	

Same amount of lining will be needed.

For pleated valance.....1 yard of double cord shirr tape for each return **For gathered valance....**1 yard of double cord shirr tape for every seam in valance, plus 1 yard for each return.

Yardage for Trims:

Trims must be able to curve.

Each 20" swag	26"
Each 26" swag	32"
Each Return	8"
Each Curved Horn	21"
Each Horn	21"