



Roman Shades

9219 A

Instructions are for Roman Shades with a straight bottom edge. Instructions for a decorative edge and with valances are in pattern package 9219 B&C. Returns can be used. They are made and attached separately.

Fabric Suggestions: While deciding on your fabric, keep in mind weight and window width. If your fabric and lining are heavy and your window is over 100" wide, you may need a motorized lift system. Blackout lining and interlining can be used. Unlined sheer fabrics are not recommended.

YARDAGE

Shade fabric.....Finished length plus 18". (One permanent fold is included).
The cut width should be 8" wider than finished width.

LiningFinished length plus 10".

Interlining (optional)Finished length plus 10".

Trim (optional)Finished width plus 2".

Sure Shade™ Lift System www.RowleyCompany.com

There is a revolution in window treatments involving lift cords as we have known them. Cords at the back of a fabric shade can pull out and form a loop. A young child can become tangled in the cords and be strangled. The Sure-Shade™ System components, upon using the appropriate fabrication techniques, will meet the standards of the American National Standards Institute (ANSI) dated September 3, 2010. Bead chain, or cord loop complies with the standards if properly installed to the wall and the Universal Drive Tension Device is used.

Instructions in this package include using the Sure Shade™ lift system components involving the roller tube and lift bands. The components needed are listed inside. Simplified instructions to assemble the system is also given. Contact the Rowley Company to order the supplies, or a kit.

This lift system must be installed to a mount board, or to the wall, if a pole is used for the shade.