

2001-2006 Hyundai Santa Fe Fuel Line Kit Nylon Hose Cutting Instructions



- 1. Identify the factory nylon fuel lines under the vehicle. The factory nylon line is molded to the hardline. Looking at the line, there will be a noticeable dimple in the line like shown in photo above.**



- 2. Cut the nylon fuel line right above that dimple. Save the factory nylon line. They will be used in the next step.**



- 3. With the supplied female quick disconnect fitting and fuel line clamp, slide the clamp over your factory nylon fuel line.**



- 4. Insert the quick disconnect fitting into the nylon.**

2001-2006 Hyundai Santa Fe Fuel Line Kit Nylon Hose Cutting Instructions



5. Slide the clamp over the barb near the middle of the fitting.



6. Using pliers, squeeze the tab in the middle of clamp.



7. Congratulations! Your fuel lines are now ready to be installed!