

## Installation Tips Chevrolet Silverado 2500HD Quick Fix Fuel Lines

Fits: 2001-2010 Chevrolet Silverado 2500HD, 3500, 3500HD 2001-2010 GMC Sierra 2500HD, 3500, 3500HD SKUs: QFF0005SS, QFF0007SS, QFF0016SS

**IMPORTANT:** This guide is not intended to be used as step by step instructions for the installation of the product, it is only intended to answer frequently asked questions and provide installation tips to guide the installation of the product.

**CAUTION:** Improper installation of the product can cause damage to the vehicle or bodily harm, do not attempt installation without proper safety equipment and experience.

**FITMENT NOTE:** This kit will not fit Cab & Chassis Model trucks. This kit only fits the trucks listed so long as they are equipped with a 6.6L Diesel engine.

Please ensure the kit you have purchased is for the correct cab and bed layout mentioned below:

QFF0005SS: Crew Cab (4 Doors), Short/Long Bed

QFF0007SS: Extended Cab (Door and a Half), Short/Long Bed

QFF0016SS: Regular Cab (2 Doors), Short/Long Bed

## **Installation Tips**

- 1. Your kit should include the following: 3 Hoses (1 Short Hose, 2 Longer Hoses) and a bag of clips/brackets.
- 2. The Short Line included in the kit is for connecting the fuel cooler to the tank, the male end should connect to the factory tank hose and the female end should connect to the fuel cooler as pictured below:



3. 1 of the 2 Long Lines should have a female fitting on one end and another female fitting on the other end. This line is intended to connect the fuel cooler to the engine.

4. The other Long Line should have a male fitting on one end and a female fitting on the other end. The male fitting connects to the factory hose that comes off of the fuel tank and the female fitting connects to the fuel pump.

## **Final Note**

We are currently in the process of making installation videos and instructions for as many of our products as possible, but for now we hope that this guide has been helpful in the process of replacing your lines. As always, if you have any further questions or concerns please feel free to call us at 330-334-3800 or email us at support@moderndaymuffler.com