



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

Product Packing List

Product: SDHQ-00-1107

Description: Utility Jug Strap Kit

____ (2) S.S. SDHQ Tie Down Buckles

SDHQ-00-1107-A

____ (1) 1" x 10' Ratchet 'S' Hook Speed Strap

- Red
- Black
- Blue

SDHQ-00-1107-RD

SDHQ-00-1107-BK

SDHQ-00-1107-BU

Inspected and Packaged By: _____ **Date:** _____

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

INSTALLATION INSTRUCTIONS

Product: SDHQ-00-1107

Description: Utility Jug Strap Kit



<u>Parts List</u>	<u>Hardware List</u>	<u>Required Tools</u>
(2) S.S. Tie Down Buckles (1) 1"x10' Ratchet 'S' hook Speed Strap	N/A	Scissors Lighter/Torch Tape Measure
<u>Tech Notes</u>		
The Tie Down Speed Strap will need to be cut to properly set up this product.		

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com



READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION!

Installation Instructions:

1. Verify all parts are present and working properly.
2. **Cutting the Strap:** The Tie Down Speed Strap will need to be cut as pictured above. To fit Scribner Cans, we recommend cutting the strap to a length of 38 ½" not including the hook. Verify this length will work on your gas can before cutting the strap.
3. Using sharp scissors, cut the Tie Down Speed Strap to the desired length. Use a lighter or a torch to singe the cut ends of the strap such that the strap will not unravel.
4. **Assembling the Speed Strap and Tie Down Buckles:** Insert the Tie Down Speed Strap into the first slot in the Tie Down Buckles as pictured below.



5. Insert the Cut Tie Down Speed Strap underneath the Tie Down Speed Strap in the first slot of the Tie Down Buckles.



6. Feed the Cut Tie Down Speed Strap into the second slot in the Tie Down Buckle. Feed the Tie Down Speed Strap over the Cut Tie Down Speed Strap in the second slot of the Tie Down Buckle.



7. Feed both Straps into the angled slots in the Tie Down Buckle.



8. Feed both Straps through the angled slots in the second Tie Down Buckle. Be sure the straps are straight and not twisted in any way.



9. Feed the Cut Tie Down Strap into the closest straight slot first, as pictured below. Proceed with feeding the Tie Down Strap afterwards.



10. Feed the Tie Down Strap into the far slot as pictured below first. Feed the Cut Tie Down Strap into that slot over the Tie Down Strap. Adjust the Buckles as needed to fit your gas can.



*****Double check all hardware is installed correctly and tight*****

*****Re-torque ALL bolts after 100 miles*****



190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929 | Fax: 480-633-1791
www.sdhqoffroad.com

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com